

Uskin Models

182 Blatchcombe Road

Paignton

Devon

TQ3 2JP

Johnbesley59@gmail.com

TE14 Swivel Seat

This kit can be mounted in two ways, (1) if the engine is run with the canopy or (2) if the engine is run without the canopy

First bolt the angle bracket to the outer lug on the seat mount and offer it up to the tender side as this will enable the correct hole spacing to be drilled for the side mount – drill this through for 10BA clearance



You now have the option of (1) or (2) if you require the canopy fitted then remove the bracket and fit the seat support to the side and drill the second hole in the tender side, bolt this in place and that's finished



If option (2) then drill through the two holes in the bracket on the rear and bolt in place

